




D

Montagefolge:

- 1: Edelstahlelement anschrauben
- 2: Steckdoseneinheit einsetzen und Leitungen zur Stromversorgung verlegen
- 3: Steckdoseneinheit anschrauben
- 4: Abdeckrahmen aufsetzen
- 5: Netzanschluß 250 Volt 50 Hz mittels Schukostecker oder als direkten Anschluß vornehmen
Braun: L1 = Phase
Blau: N = Nulleiter
Grün/Gelb: SL/ PE = Schutzleiter

! Achtung: Alle Montagearbeiten in spannungslosen Zustand durchführen. Bitte beachten Sie die jeweils gültigen VDE Richtlinien. Änderungen an den Elementen oder deren Bauteile sind nicht gestattet

Reinigungshinweis:

Um Beschädigungen an der Oberfläche zu vermeiden, bitte keine Scheuermittel und Putzschwämme verwenden! Verwenden Sie nur für Edelstahl geeignete silikonhaltige Reinigungsmittel!

UK

Assembly sequence

- 1: Screw on stainless steel element
- 2: Insert power strip and lay cables for power supply.
- 3: Screw on power strip
- 4: Put on cover frame
- 5: Mains connection 250 Volt 50 Hz by means of Schuko plug or as direct connection make
Brown: L1 = Phase
Blue: N = Neutral
Green/Yellow: SL/ PE = protective conductor

! Attention: Carry out all assembly work in a de-energized state. Please observe the applicable DIN VDE 0100 guidelines or national rules. Modifications to the elements or their components are not permitted.

Cleaning instructions:

To avoid damage to the surface, please do not use scouring agents and cleaning sponges! Use only silicone-containing cleaning agents suitable for stainless steel!