





D

Montagefolge:

A:Edelstahl: Steckdosenelement positionieren und mittels Schrauben (2) anschrauben Teleskopstück in Endposition aufklippen

A: Schwarz: Teleskopstück aufsetzen (1), Element positionieren, untere Befestigungsschraube (2) eindrehen, Teleskopstück in Endposition bringen (3) und obere Befestigungsschraube (4) eindrehen, abschließend beide Befestigungsschrauben fest andrehen

B: Schraubenlöcher mittels Blindstopfen verschliessen

C: Netanschlussleitung verlegen, bitte darauf achten dass die Leitung vor Beschädigung geschützt verlegt wird.

E: Netzanschluss 250 Volt / 50 Hz direkt oder mittels Schutzkontaktstecker vornehmen


Achtung: Alle Montagearbeiten in spannungslosen Zustand durchführen

Bitte beachten Sie die jeweils gültigen VDE Richtlinien.

Änderungen an den Elementen oder deren Bauteile sind nicht gestattet

Reinigungshinweis


Um Beschädigungen an der Oberfläche zu vermeiden, bitte keine Scheuermittel und Putzschwämme verwenden! Verwenden Sie nur für Edelstahl geeignete silikonhaltige Reinigungsmittel!



USB Varianten:

USB A =	5V / 2300 mA
---------	--------------

USB A/C =	5V / 2300 mA
-----------	--------------



UK

Assembly sequence:

A:Stainless steel: Position socket element and screw on using screws (2). Clip on telescopic piece in end position

A: Black: Place telescopic piece (1), position element, screw in lower fastening screw(2), bring telescopic piece into end position (3) and screw in upper fastening screw (4), finally tighten both fastening screws

B: Close screw holes with blind plugs.

C: Lay the power supply cable, please make sure that the cable is protected against damage from damage.

E: make the main connection 250 V/50 Hz direct, or w/ plug

Attention: The applicable VDE rules must be observed, see DIN VDE 0100, or national rules.

Make sure the power supply is disconnected before carrying out any mounting work

Changes to the socket element or any cords and connections are not permitted

Cleaning instructions:

To avoid damage to the surface, please do not use scouring agents and cleaning sponges!

Use only silicone-containing cleaning agents suitable for stainless steel!